



31. BATTERY SAVER CIRCUIT



a. CONNECTOR INFORMATION


CONNECTOR(No.) (PIN NO. COLOR)	CONNECTING, WIRING HARNESS	CONNECTOR POSITION
C102 (32 Pin, Gray)	Front – Engine Fuse Block	Engine Fuse Block
C201 (76 Pin, Black)	I.P – I.P Fuse Block	I.P Fuse Block
C202 (20 Pin, White)	I.P – I.P Fuse Block	I.P Fuse Block
C203 (18 Pin, White)	I.P – I.P Fuse Block	I.P Fuse Block
C208 (20 Pin, Yellow)	Front – I.P	Front TCM
C209 (4 Pin, White)	Front – I.P	Front TCM
C214 (22 Pin, Black)	I.P – Floor	Under Left A Pillar
G201	I.P	Upper Mirror Control Switch

b. CONNECTOR IDENTIFICATION SYMBOL & PIN NUMBER POSITION




c. POSITION OF CONNECTORS AND GROUNDS

- W/H I/P



S6B12001

- W/H FLOOR



S6B12003